



## OPERATION STEP



## FUNCTION AND SPECIFICATION



## SPECIFICATION

- **Output RMS** 28W
- **Impedance** 6Ω Bass / 4Ω Satellite
- **Signal-to-Noise Ratio** 62dB
- **Frequency Response** 45Hz~20KHz
- **Power Input** AC 220V-50Hz
- **Dimension**
  - **Subwoofer** W137 X H203 X D253 mm
  - **Satellite** W88 X H166.5 X D82 mm
- **Function** Plug & play music from Flash Drive / MMC Card / SD Card
- **Magnetically Shield** Yes

## WARNING

Don't place the product in the high temperature. Moist and place the product on a secure, stable surface. The product can cause serious damage if it fall.

Never open the product by yourself. It is an electrical shock hazards. If the repair is needed, It should be done by qualified electrician.

Take out all power cords immediately and do not use the product if damaged or water enter into the product with carelessness.

Do not maximize the volume when it is connected with the equipment which has output power. It causes sound it dispropotion.

Use the product only in indoor.

Unplug the product only in indoor.

Unplug the power outlet, if you won't use more than two days.



## MANUAL BOOK

# CST 1500N+

Active Multimedia Subwoofer System



## MUSIC PLAYER



**N**  
SERIES

**simbadda**