5.Charge: Please connect the USB charge cable with computer or 5V adapter. When it is charging the light indicate red. The red light will off when charge full.

WARNING

To prevent any risk of fire or electrical hazard, do not open or replacement any parts by yourself, if the product is damaged. Please contact qualified service personnel or designated repair center.

- 1.Water and Moisture the unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
- 2.Objects and Liquid Entry Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
- 3. Heat the unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- 4.To place your product on a stable, level countertop.
- 5.Do not put any other item on the product.
- 6. When you press the buttons, to avoid force to damage the product.
- 7.For your safety, please care to use and protect the USB cable.
- 8.Cleaning the unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.

MANUAL BOOK

CST 330N



enjoy music anytime, everywhere!







simbadda

MUSIC PLAYER Simbadda

dda Music Player

simbadda

MUSIC PLAYER

simbadda






Spesification


R.M.S: 5Watt S/N Ratio: 60db

Battery: 3.7V / 850mAhSpeaker driver: $4\Omega / 1.5$ "

Frequency response: 50Hz-20KHz Dimension: L120 x W62 x H55 mm Function: Bluetooth, Micro SD, AUX-IN







Function

- 1. Mode
- 2. Previous track / Volume down
- 3. Next track / Volume up
- 4. Play / Pause
- 5. Micro SD card
- 6. LED lamp
- 7. AUX IN
- 8. Charging input
- 9. On / Off

Button Function

- **1.**Short press mode (M) to music mode.
- 2. ◄ /- Previous track and volume down.
- 3.►►I/+ Next track and volume up.
- **4.**▶► Play or pause track and pairing bluetooth.

Using The Speaker

- 1. Turn on the power switch to the "ON" position at first, the bluetooth light glows, and the speaker will automatically enter into pairing mode. Now you can find the bluetooth name in your mobile phone or other bluetooth device. Then connect them is okay. You can play the music now.
- **2.**Micro SD Mode: When insert the Micro SD, the speaker will change to Micro SD mode automatically.
- **3.**AUX MODE Connect the 3.5mm audio cable with mobile or PC, it will play music through AUX mode.



